



| | | | | | | | | |
|----------|------------|------------|----------|------------|------------|----------|------------|------------|
| LM5AUU | | | LME5AUU | LME5AUUAJ | | | | |
| LM6AUU | LM6AUUAJ | | LME8AUU | LME8AUUAJ | | LMB6AUU | LMB6AUUAJ | |
| LM8SAUU | LM8SAUUAJ | | LME10AUU | LME10AUUAJ | LME10AUUOP | LMB8AUU | LMB8AUUAJ | LMB8AUUOP |
| LM8AUU | LM8AUUAJ | | LME12AUU | LME12AUUAJ | LME12AUUOP | LMB10AUU | LMB10AUUAJ | LMB10AUUOP |
| LM10AUU | LM10AUUAJ | LM10AUUOP | LME16AUU | LME16AUUAJ | LME16AUUOP | LMB12AUU | LMB12AUUAJ | LMB12AUUOP |
| LM12AUU | LM12AUUAJ | LM12AUUOP | LME20AUU | LME20AUUAJ | LME20AUUOP | LMB16AUU | LMB16AUUAJ | LMB16AUUOP |
| LM13AUU | LM13AUUAJ | LM13AUUOP | LME25AUU | LME25AUUAJ | LME25AUUOP | LMB20AUU | LMB20AUUAJ | LMB20AUUOP |
| LM16AUU | LM16AUUAJ | LM16AUUOP | LME30AUU | LME30AUUAJ | LME30AUUOP | LMB24AUU | LMB24AUUAJ | LMB24AUUOP |
| LM20AUU | LM20AUUAJ | LM20AUUOP | LME40AUU | LME40AUUAJ | LME40AUUOP | LMB32AUU | LMB32AUUAJ | LMB32AUUOP |
| LM25AUU | LM25AUUAJ | LM25AUUOP | LME50AUU | LME50AUUAJ | LME50AUUOP | LMB40AUU | LMB40AUUAJ | LMB40AUUOP |
| LM30AUU | LM30AUUAJ | LM30AUUOP | LME60AUU | LME60AUUAJ | LME60AUUOP | LMB48AUU | LMB48AUUAJ | LMB48AUUOP |
| LM35AUU | LM35AUUAJ | LM35AUUOP | LME80AUU | LME80AUUAJ | LME80AUUOP | LMB64AUU | LMB64AUUAJ | LMB64AUUOP |
| LM40AUU | LM40AUUAJ | LM40AUUOP | | | | | | |
| LM50AUU | LM50AUUAJ | LM50AUUOP | | | | | | |
| LM60AUU | LM60AUUAJ | LM60AUUOP | | | | | | |
| LM80AUU | LM80AUUAJ | LM80AUUOP | | | | | | |
| LM100AUU | LM100AUUAJ | LM100AUUOP | | | | | | |
| LM120AUU | LM120AUUAJ | LM120AUUOP | | | | | | |
| LM150AUU | LM150AUUAJ | LM150AUUOP | | | | | | |